
## **LED Tri-proof Lighting Manual**




## (n) ( € (v) ≥ IP65 IK08





## **General Safety Information**

- Installation, commissioning and maintenance only by qualified electrician
- Never perform any work on the luminaire with voltage applied.
   Danger to life due to electric shock!
   Electric connection must be appropriate according to all
- applicable standards and other national and international safety and accident prevention regulations.
- Damaged luminaires must not be operated.
  Observe and retain safety instructions and mounting instructions
- No liability is accepted for damages resulting from improper
- use.


   Use genuine parts only for repair.











3
























ССТ	EET
4000/5000K	В
3000/6500K	С



This product contains a light source of energy efficiency class <C>.(3000K/6500K)



## Replace method:

- 1. Open the endcap and take out the module.
- 2. Remove the cables and plastic clips connecting the PCB board or screws on the power supply.
- 3. Replace the PCB board or driver with new one.

